










# KIT DE SOUFFLET/BOOT KIT

<p><b>ADB06</b></p> <p>Dimensions: .750 (width), 4.035 (height), 2.645 (seal diameter)</p>	<p><b>ADB16</b></p> <p>Dimensions: .668 (width), 3.190 (height), 2.298 (seal diameter)</p>	<p><b>ADB24</b></p> <p>Dimensions: .915 (width), 3.545 (height), 2.990 (seal diameter)</p>
<p><b>ADB27</b></p> <p>Dimensions: .735 (width), 4.135 (height), 2.860 (seal diameter)</p>	<p><b>ADB32</b></p> <p>Dimensions: .835 (width), 3.750 (height), 3.190 (seal diameter)</p>	<p><b>ADB34</b></p> <p>Dimensions: .760 (width), 3.192 (height), 2.603 (seal diameter)</p>
<p><b>ADB36</b></p> <p>Dimensions: .840 (width), 4.255 (height), 2.893 (seal diameter)</p>	<p><b>ADB38</b></p> <p>Dimensions: .897 (width), 3.640 (height), 2.915 (seal diameter)</p>	<p><b>ADB52</b></p> <p>Dimensions: .850 (width), 3.815 (height), 3.052 (seal diameter)</p>

# KIT DE SOUFFLET/BOOT KIT

<p><b>ADB53</b></p> <p>3.960</p> <p>.791</p> <p>2.600</p>	<p><b>ADB54</b></p> <p>4.365</p> <p>.885</p> <p>2.655</p>	<p><b>ADB56</b></p> <p>3.660</p> <p>.995</p> <p>3.085</p>
<p><b>ADB60</b></p> <p>3.350</p> <p>.680</p> <p>2.392</p>	<p><b>ADB61</b></p> <p>3.430</p> <p>.750</p> <p>2.550</p>	<p><b>ADB62</b></p> <p>3.550</p> <p>.725</p> <p>2.665</p>
<p><b>ADB71</b></p> <p>3.890</p> <p>.905</p> <p>3.030</p>	<p><b>ADB120</b></p> <p>3.485</p> <p>.820</p> <p>2.860</p>	<p><b>ADB159</b></p> <p>3.350</p> <p>.680</p> <p>2.392</p>

# KIT DE SOUFFLET/BOOT KIT

<p><b>ADB217</b></p> <p>↔ .905</p> <p>↑ 3.890</p>  <p>↔ 3.030</p>	<p><b>ADB316</b></p> <p>↔ .758</p> <p>↑ 3.561</p>  <p>↔ 3.010</p>	<p><b>ADB371</b></p> <p>↔ .715</p> <p>↑ 3.885</p>  <p>↔ 2.365</p>
<p><b>ADB461</b></p> <p>↔ .7</p> <p>↑ 3.05</p>  <p>↔ 2.22</p>	<p><b>ADB518</b></p> <p>↔ .905</p> <p>↑ 3.890</p>  <p>↔ 3.030</p>	<p><b>ADB651</b></p> <p>↔ .725</p> <p>↑ 3.550</p>  <p>↔ 2.665</p>
<p><b>ADB712</b></p> <p>↔ .735</p> <p>↑ 4.135</p>  <p>↔ 2.860</p>	<p><b>ADB921</b></p> <p>↔ 1.05</p> <p>↑ 5.7</p>  <p>↔ 3.1</p>	<p><b>AD002</b></p>  <p>2 COLLETS 30MM 2 COLLETS 74MM 2 COLLETS 80MM</p>

# KIT DE SOUFFLET/BOOT KIT

## AD013



1 SACHET DE GRAISSE  
1 COLLET 30MM  
1 COLLET 85.5 MM MULTI

## AD014



1 SACHET DE GRAISSE  
1 COLLET 35MM  
1 COLLET 92MM

## AD015



1 SACHET DE GRAISSE

## COLLETS DE CARDAN



# 10900022 61.5 MM A 85.5 MM  
# 15900006 25 MM A 50 MM  
# 16300022 23.6 MM A 30 MM  
# 16300023 28.6 MM A 35 MM  
# 16300030 65.5 MM A 74 MM  
# 16300031 71.5 MM A 80 MM  
# 16300032 77.5 MM A 86 MM  
# 16300033 83.5 MM A 92 MM